



# DualShock 3 Teardown

This is a simple teardown on how to teardown your Dualshock PS3 controller and put it back together.

Written By: Diego Figueroa





## Step 1 — DualShock 3 Teardown



- First step you would have to do would be to unscrew five screws from the back of the controller.



## Step 2



- After you unscrewed all five screws in the back, next you're going to have to gently pull both of the controller sides apart and it will come straight off.




## Step 3



- Then you have to take off the battery and you have to be very careful, if you break the battery your controller wont work.


## Step 4



- There are two screws and you are going to unscrew one from above and the bottom.



## Step 5



- Then you are going to take off these analog sticks.
- ( You can put the analog sticks back on )

## Step 6



- Then you will be able to lift right off the other stuff that will be left.

## Step 7



- and now you have all your parts of your DualShock 3 PS3 controller all scattered, to put it back together you would just have to follow the steps backwards.

---

This document was last generated on 2017-08-06 05:57:50 AM.